

## Container Handler

Used Container Handler Alabama - Container handlers are also called container ships and cargo ships since they transport loads in sizeable intermodal containers. Containerization is the shipping method that utilizes commercial freight transport to carry seagoing cargo in non-bulk sizes. The capacity of container ships is measured in units equivalent to twenty-foot equivalent loads. The majority of typical loads consist of a mix of 40-foot containers and 20-foot containers. Approximately ninety percent of non-bulk cargo across the globe is transported by container ships. Container handlers are one of the biggest vessels sailing and are the main rival for oil tankers on the ocean. Dry cargo is categorized into two main types: break-bulk cargo and bulk cargo. Grain and coal fall into the bulk cargo category. They are often moved in their raw form, package-free in large volumes in the hull of the ship. Break-bulk cargo items normally consist of manufactured goods that are transported in packages. Prior to containerization being invented in the 1950s, break-bulk materials were loaded, secured, unlashed and unloaded one piece at a time from the ship. When the cargo was grouped into containers, there were approximately 1000-3000 cubic feet of cargo that can be simultaneously moved after each unit has been standardized and secured. Break-bulk cargo shipping has greatly increased overall efficiency. Thanks to these new systems, shipping time has been reduced by eighty-four percent and costs have come down by roughly thirty-five percent. More than ninety percent of non-bulk items were recorded as being transported in containers in 2001. The first cargo ships were born in the 1940s as redesigns from World War II tankers. Container ships do not rely on individual hatches, holds and dividers that are part of regular cargo ships. The typical container ship's hull is a basically a large warehouse that is divided by vertical guide rails into cells. The cargo in the containers is held by these specially designed cells. Most shipping containers are constructed from steel; however, additional materials including plywood, fiberglass and wood are used. As containers have been designed to completely transferred to and from coastal carriers, semi-trailers, trucks, trains and more, these containers are categorized due to their function and size. Containerization has revolutionized the shipping industry; however, it did not start out in the easiest fashion. Initially, ports, railway companies and shippers were concerned regarding the extensive costs that came with constructing infrastructure, ports and railways required to accommodate the cargo ships and transporting items with rail and roads. There was skepticism regarding potential dock and port worker job loss when containerization was announced for fear that numerous manual jobs would disappear. Approximately ten years of legal battles occurred prior to container ships began international service. A container liner service from the Dutch city of Rotterdam to the USA first started in 1966, soon to change world trade and shipping across the globe. Loading and unloading of cargo ships has been reduced to a few hours instead of the days it used to take traditional cargo vessels. Shipping times have been shortened in between ports extensively along with labor finances. It only takes 3 weeks to have materials delivered from Europe to India as opposed to the months it used to require. There is generally less damage to goods due to less handling. Less cargo shifting during a voyage is also beneficial. Containers are sealed prior to shipping and opened only once they arrive at their destination, resulting in less theft and disruption. There have been less shipping expenses and shipping time thanks to container ships which has increased international trade. Cargo that used to arrive in bales, crates, bags, cartons or barrels now arrives in containers sealed from the factory. There is a product code on the contents utilized by scanning machines and computers to trace. Technology has made this tracking system accurate and exact to enable a two week voyage to be timed for arrival within an accuracy rate of under fifteen minutes. This has helped with guaranteed delivery and manufacturing times. Sealed containers of raw materials arrive in under an hour to be used in manufacturing facilities, resulting in less inventory costs and higher accuracy. The shipping companies supply the exporters with boxes for loading products. Materials are delivered by rail or docks or a combination of both and then loaded into container handlers. Before containerization, it would take large groups of men and many hours

fitting cargo items into different holds. The shipping industry today relies on cranes either installed on the ship or on the pier to situate containers on board. After the hull has been fully loaded, additional containers can be attached to the deck. Efficiency has been one of the main design elements for cargo ships. Containers may travel on break-bulk vessels. Designated cargo hold on container ships have been built to increase efficiency during loading and unloading to ensure safe travel. There is a sophisticated hatch design to allow openings from the main deck to reach the cargo hold locations. These openings flow along the whole cargo hold area and are surrounded by the hatch coaming which is a raised steel structure. There are hatch covers located on top of the hatch coamings. Wooden boards and tarps initially covered the hatches and held the battens secure until the 50s. Hatch covers are made of secure metal plates and cranes are used to lift them on and off of the ship. There are other hatch models that rely on articulated mechanisms that use strong hydraulic rams for opening and closing. Cell guides are a necessary component in cargo ship design. These vertical structures are made of strong metal that is attached to the cargo hold on the ship. These guide the containers into certain locations and offer travel support on the high seas. The design of the container ship uses cell guides enough that the United Nations Conference on Trade and Development utilize them to distinguish between container ships and regular break-bulk cargo ships. There is a system used in cargo plans consisting of three dimensions to outline a container's position aboard the ship. The bay is the first coordinate, starting at the front of the container ship and increases aft. The tier forms the second coordinate. It starts in the bottom area of the cargo holds and the second tier is located on top of the first one and continues to grow. The third coordinate is found in the third row. Rows found on the port side of the ship exhibit even numbers and those located on the starboard side are given odd numbers. The cargo situated near the centerline showcases lower numbers and as the cargo increases further from the center, the numbers get higher. Container handlers carry 20, 40 and 45 foot containers. The biggest sizes only fit above the deck. The forty-foot containers comprise most of the load or roughly 90% of container shipping. Approximately 90% of the freight moves across the globe with container shipping. It is estimated that 80% of global freight travels with 40-foot containers.